


# Bike Mount Installation Tool

P/N YAAC1986



Application: All YETI models




## General guidelines

- 1 - Install one of the washers (3) on bolt (4).
- 2 - From inside the Bike Mount, pass bolt (4) through upper hole located at the front.
- 3 - On outside of Bike Mount, install other washer (3), and nut (2) on bolt (4).
- 4 - Inside, install split bushing (1) between washer (3) and Bike Mount.
- 5 - Rotate nut (2) to bring assembly together and engage adapter in Bike Mount.
- 6 - Continue rotating nut (2) until insertion of adapter in Bike Mount is complete.

For more information, see “Mount Adapter Installation” section in the **User Manual**.

The **Bike Mount installation tool** is used to press bike-specific adapters in the Bike Mount. The following figures illustrate how the tool is used on the YETI Conversion System.

## Pressing Adapters in Bike Mount




# Outil d'installation du support de fixation

N/P YAAC1986




Application : tous les modèles YETI



Réf	Description	Qté
1	Tool, bushing, bike mount adaptor	1
2	HN, M8-1.25, 8, ZP	1
3	FW, 5/16 - M9	2
4	HCS, M8-1.25X150, 8.8, ZP, DIN933	1

L'ensemble **Outil d'installation du support de fixation** est utilisé pour insérer les adaptateurs de fixation (variant selon le modèle de moto) au support du châssis. Les figures suivantes illustrent l'application de l'outil au système YETI.

## Insertion des adaptateurs au support de fixation



## Directives générales

- 1 - Installer une rondelle (3) sur boulon (4).
- 2 - De l'intérieur du support de fixation, passer le boulon (4) par le trou supérieur à l'avant du support.
- 3 - À l'extérieur du support, l'autre rondelle (3) et l'écrou (2) sur le boulon (4).
- 4 - À l'intérieur, installer la douille fendue (1) entre la rondelle (3) et le support de fixation.
- 5 - Tourner l'écrou (2) pour maintenir en place l'assemblage et engager l'adaptateur dans le support de fixation.
- 6 - Continuer de tourner l'écrou (2) jusqu'à ce que l'insertion de l'adaptateur dans le support de fixation soit complétée.

Pour plus de renseignements, voir la section «*Installation des adaptateurs de fixation*» du **Manuel de l'utilisateur**.